

ADUROSMART

USER MANUAL WIRELESS MOTION SENSOR

Place the 2 AAA batteries in the battery compartment take note of the - and + on the battery compartment.

2A. Download the Adurosmart App from the Apple App Store or from Google Play or go to http://adurosmart.com/adurosmart-app/

Connect with the ERIA hub

8. Press on "Motion Sensor"



. Hub

ᇛ

? Help center

Press on "Brands" and then select "AduroSmart ERIA".

10. Proceed by pressing on "Search" to allow the Adurosmart ERIA hub to find the sensor, the LED indicator on the hub will **flash green** this indicates that the hub is searching for new devices.





If you are experiencing issues while connecting the Sensor then please follow below instructions to reset the sensor.

Locate the small pinhole button on the sensor, use a small pin or paperclip to press the button for 10 seconds the sensor LED indicator will flash quickly to confirm the reset.

LED will flash once per second for approximately 1 min.

LED will stop flash.

LED will flash fast.

LED will flash once quickly.

j 10 seconds

Connection mode Connection successfully

Sensor triggered (when the sensor is opened for more than 10mm)

Sensorreset

