

Update 2.2.2. MOES Tuya WiFi Motion Sensor oplaadbaar/rechargeable

Engels;

1. First pair the MOES Motion Sensor with the Internet via the Tuya or Smart Life App, if not already done so, and then turn off the battery switch.
2. Turn on the battery switch while pressing the wifi pairing button.
You can release the button after 5 seconds.
The indicator light is off at this time, then click on the corresponding product upgrade button in the mobile APP.
3. After the upgrade is completed, turn off the battery switch and finally turn it on.

Nederlands;

1. Verbind eerst de MOES Bewegingssensor met Internet via de Tuya of Smart Life App, mocht je dit nog niet gedaan hebben, en zet het batterij knopje op Off.
2. Houd het WiFi Pair knopje ingedrukt terwijl je de Batterij knop op On zet, en hou dan de knop nog 5 seconde ingedrukt. Het indicatie ledje is nu uitgeschakeld, en klik je in de app op Update/Upgrade
3. Na het voltooien van de Update, zet het batterij knopje even op Off en daarna op On, en dan werkt de MOES Motion Sensor weer met de nieuwe update.