


Water Leak Detector User Manual


Product Description



Entering the Network Configuration Mode 1. Power on the product.




Insert a thin blade or coin into the slot on the battery cover and rotate it counterclockwise to open the battery cover.



Remove the battery insulation film to power on the product and close the battery cover.

2. Press and hold the button for 5s to restore the product to

factory settings. The status indicator will rapidly blink green, and the product will automatically enter the network configuration mode once




the factory settings have been restored.

- Press and hold the hutton for 5s to 10s to make the product enter the network
- will be steady green for 5s and the product will report its status. If the product fails to enter the network configuration mode, the status indicator is off.

Installation Instructions

Place the product in the detection area.





Technical Parameters

Wireless Technology	Zigbee
Working Voltage	3 V (CR2032 battery)
Transmission Frequency	2.4 GHz
Working Temperature	-10°C to +55°C
Undervoltage Alarm	Supported
Undervoltage Alarm	Undervoltage Alarm
Battery Lifespan	More than one year (20 times per day)
Dimensions	F50 mm x 18 mm

Toxic or Hazardous Substances or Flements of this Product

	Toxic or Hazardous Substances or Elements					
Component Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr (VI))	Polybrominated biphenyls (PBBs)	Polybromi diphenyl e (PBDE
LED	0	0	0	0	0	0
PCB	×	0	0	0	0	0
Cover and other components	×	0	0	0	0	0

exceeds that stinulated in GB/T 26572

- This table complies with SJ/T 11364. homogeneous materials of a component does not exceed that stipulated
- in GB/T 26572 X: indicates that the toxic or hazardous substance amount contained in at least one of the homogeneous materials of a component

Warranty Certificate

Warranty policy:

- 1. If the product has quality problems within 7 days of the payment
- date, you can apply for a refund based on the invoice price or to replace the product with one of the same model
- 2. If the product has quality problems within 15 days of the payment date, you can apply to replace the product with one of the same 3. If the product has quality problems within 12 months of the payment date, you can apply to have the product repaired.
- What is not covered under this warranty:
- 1. The product owner has no warranty certificate or the warranty
- service has expired. 2. Damage caused by improper use, maintenance, or storage
- 3. Damage caused by disassembly and repair without Tuya's
- authorization 4. Damage caused by force majeure
- 5. Normal discoloration and depreciation after the product has been

User Form

User information (Specify real information, Tuya promises to use the information only for after-sales services.)

Name	1
Phone number	
Email	

Product information

Service Return Replace Repair

Fault symptoms

Handling date

Maintenance personnel signature

Name	M

Zip code _____

Address

Product SN

	C	0	Į

Product information	n
Name	
Color	
00101	

Address

_	— Product	SN		
)	Replace	\bigcirc	Repair	\bigcirc

Vendor Form

User information (Specify real information, Tuya promises

Phone number

to use the information only for after-sales services.)

Ser	vice	Return	\circ	Replace	1
_					

7 in code

	_	 \sim	
mptoms			_

att symptoms	
ndling date _	

p	
date	

S			

Handling d	ate		
_			ī
Maintenand	e personnel:	signature .	